

BLAZE KING WOOD STOVES

1. Remove catalytic thermometer and cast top from stove. **(Fig A)**

Fig A



2. Bolt side shelf assembly to cast hanger using two washers and two M6 x 12 mm hex cap screws. **(Fig B)**

3. Place cast top and catalytic thermometer back onto the stove.

Fig B

